

Electra Small Headset Mounted Wire Basket Assembly Guide

Electra

1) Tools Needed

- 8 mm open end or box wrench (or small adjustable wrench)
- 32 mm open-end wrench - for bikes with 1" headsets (or large adjustable wrench)
- 36 mm open-end wrench - for bikes with 1 1/8" headsets (or large adjustable wrench)
- 6mm hex head wrench



2) Parts List

- (1) small wire basket
- (1) steel plate buckle w/ridge (3 cm x 4.5 cm)
- (4) nylon lock nuts
- (4) hex head machine bolts w/washers, 12mm long
- (4) steel washers
- (2) steel inner plate (7 cm wide x 1.5 cm thick)
- (1) headset bracket for 1" headset-equipped bikes
- (1) headset bracket for 1 1/8" headset-equipped bikes



Electra Small Headset Mounted Wire Basket Assembly Guide

Electra

STEP 1: Installation of headset bracket

- 1) Remove stem/handlebar combination using a 6 mm hex wrench
- 2) Remove top nut using 32, 36 mm or adjustable wrench and put aside
- 3) Remove steel key washer
- 4) Install mounting bracket in place of key washer, lip side faces up
- 5) Reinstall top nut using 32, 36 mm or adjustable wrench
- 6) Reinstall stem/handlebar combination using a 6 mm hex wrench

Note: Most Electra Cruiser models use 1" headsets while Townie models use 1 1/8" headsets. If mounting to a late-model Townie, it is necessary to remove the conical headset spacer. Put spacer aside for future use if basket is no longer installed. If you are unsure of the size of your headset, contact your local Electra dealer.

STEP 2: Attaching basket to headset bracket

- 1) Thread hex head bolts through steel washers and inner plate
- 2) Thread hex head bolts into headset bracket and additional washers
- 3) Install nylon lock nuts, tighten

If you have questions regarding assembly, please visit your local Electra dealer or call Electra Customer Care at 800-261-1644 (8AM - 4PM Pacific Time).

